POTTERYBARN

Mercer Tube Sconce Assembly Instructions

Important Safety Instructions:

- These instructions are provided for your safety. It is important that they are read carefully and completely before installing fixture.
- This product must be installed in accordance with the applicable installation codes by a person familiar with the construction and operation of the product and the hazards involved.
- This fixture has been rated for up to (2) 14-WATT MAXIMUM TYPE T5 Fluorescent Tubes (not included). To avoid the risk of fire, do not exceed the recommended wattage.
- Save these instructions.

WARNING: This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging and lay the items out on a clear work surface.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Parts Included:

- (1) Mounting Plate (A)
- (1) Fixture Base (B)
- (1) Shade Cap (C)
- (1) Glass Cylinder (D)

Hardware Included:

- (2) Mounting Screws (E)
- (4) Base Screws (F)
- (1) Set Screw (G)

Installation Instructions:

- 1. This light fixture can be mounted horizontally or vertically.
- 2. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
- 3. Remove shade cap (C) from fixture base (B) by unscrewing set screw (H).
- 4. Plug fluorescent tubes (not included) into sockets.
- 5. Insert one end of glass cylinder (D) to shade holder. Replace the shade cap (C) to fixture base (B) and secure with set screw (G).
- 6. Remove mounting plate (A) from fixture base (B) by unscrewing base screws (F).
- 7. Wrap the ground wire (green) to around the ground screw found on the mounting plate or connect it to the ground wire found in the wall outlet box (usually green or copper in color). If attaching to ground wire in outlet box, fasten together with a plastic wire connector and tightly wrap the connection with electrical tape to seal the connector. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- 8. Connect the neutral (white) fixture wire to the neutral (usually white) outlet wire. Fasten together with a plastic wire connector and tightly wrap the wire connector with electrical tape.
- 9. Repeat this procedure with the hot (black) wires. Always make sure that no wire strands are left outside the connectors.
 - DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
- 10. Affix mounting plate (A) to the wall outlet box with mounting screws (E) provided.
- 11. Attach fixture base (B) to the affixed mounting plate (A) by aligning the holes and inserting base screws (F) on fixture base (B). Tighten with screwdriver.
- 12. Restore power and test fixture.
- 13. Installation is complete.

Care Instructions:

- Wipe with dry cloth only
- Avoid the use of all detergents and chemicals

