POTTERYBARN

GYPSY HOOK

Assembly Instructions

Note: For safe mounting, Pottery Barn recommends the following:

- Stud mounting is preferred over dry wall mounting when possible.
- Consult your local hardware store if you have any questions about installing your Accessories.
- Tools needed for installation: Phillips head screwdriver, Measuring Tape, Level and Pencil

Parts Included:

- 2 Screws
- 2 Wall Anchors

Pre-Assembly:

- Remove all parts from the box and lay out on a clear workspace, along with any plastic protective packaging. Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts list above to identify and separate each of the pieces included.
- Please note failure to follow these instructions may cause improper assembly.

Stud Mounting Instructions:

- 1. Use a measuring tape and a level to determine the proper placement of the hook.
- 2. Locate interior wood studs through wall. Place the hook over the wood stud at the desired height. Mark the location of the pre-drilled hook mounting holes on the wall with a pencil.
- 3. Align the hook mounting holes with the pencil markings; making sure the smooth surface of the hook is against the wall. Insert the metal screws through the holes on the hook. Using a screwdriver, turn the screws clockwise until the hook is secured snugly to the wall.

Dry Wall Mounting Instructions:

- 1. Place the hook at the desired height.
- Use a measuring tape and a level to determine the proper placement of the hook.
- 3. Mark the location of the hook mounting holes on the wall with a pencil.
- 4. Using a Phillips head screwdriver screw the two dry wall anchors directly into the wall at the two pencil marks. Do not "push" the anchor; it is designed to bore into the wall like a drill bit. Slowly turn the anchor clockwise while applying pressure until the flange just touches the wall.
- 5. Align the hook mounting holes with the anchor screws; making sure the smooth surface of the hook is facing the wall. Insert the metal screws through the hook holes and place into the wall anchor holes. Using a screwdriver, turn the screws clockwise until the hook is secured snugly to the wall.

Care Instructions:

- Wipe with a soft, dry cloth only.
- Avoid cleaners and abrasives as they may damage the finish.

Thank you for your purchase stores | catalog | www.potterybarn.com

