## POTTERYBARN

# assembly instructions outdoor shower

*Note:* Please read all instructions before beginning assembly. Do not tighten bolts until all are located in the correct positions noted below. We recommend assembly by two people for ease and safety.

There are no heat controls on this shower. The temperature of water will depend solely on your water source.

#### Parts Included:

Base (A)

Soap Dish (B)

Right Leg Frame (C1) Left Leg Frame (C2) Bottom Frame (D)

Upper Frame (E)

(2) Dowels (F) Allen Wrench (G)

Shower Head (H)

Curved Rod (I)

Straight Rod (J) Knob with Sealer (K)

#### Hardware Included:

(4 + 1 extra) 1 ½ " bolts (L)

(6 + 1 extra) 1 1/4" bolts (M)

(4 + 1 extra) 5/8" screws (N)

(2 + 1 extra) wing bolts (O)

(6 + 1 extra) wooden caps (P)

(1) white plastic washer (Q)

(1) black rubber ring (R)

(1) nut (S)

### Assembly Instructions:

- 1. Place bottom frame (D) on a flat surface. Connect right leg frame (C1) and left leg frame (C2) to it by fitting dowels (F) into holes and then securing with 1 ½" bolts (M). See illustration 1.
- 2. Attach upper frame (E) to previously assembled lower frame using wing bolts (O). Do not thoroughly tighten until all assembly is completed. Then attach the previously assembly frame to the base (A) with 1 ½" bolts (L). See illustration 2.
- 3. Stand shower frame upright. Place wooden caps (P) over screw holes on the frame. Attach the soap dish (B) using 5/8" screws (N). See illustration 3.
- 4. Screw shower head (H) to curved rod (I). Screw previously assembled rod to straight rod (J). Attach nut (S), white plastic washer (Q) and black rubber ring (R) to the bottom portion of the shower rod. See illustration 4.
- 5. Screw knob with sealer (K) into the front of the wooden shower frame, then attach previously assembled shower rod to the knob with sealer (K). See illustration 5.

- 6. Tighten pre-assembled side screws on knob with sealer using the allen wrench (G). See illustration 4.
- 7. Tighten all screws and bolts to secure.

#### Using your shower:

Attach garden hose to the opening on the back of the shower frame. Your water source must be turned on for the shower to operate. Be sure to place outdoor shower in a location with adequate drainage.

Insert illustrations in this area.