

POTTERY BARN

Cast Iron Row of Hooks Mounting Instructions

This row of hooks includes three holes through which provided mounted hardware passes for wall-mounting.

Max. Load : 30 Pounds Total

Hardware Included: (3) Anchors, (3) Screws

Tools Needed: Phillips Screwdriver, Pencil, Stud-Finder, Level

- 1) Hold the item upright and level against a wall at a desired mounting location. Use a level to ensure that the item is level and then use a pencil to mark the wall through each of the three mounting holes. Set the item aside.
- 2) The provided anchors cannot penetrate wood studs. Therefore we have to determine if any of the three marks of Step (1) happens to align with a wall stud. Use a stud-finder to determine this. If any mark does align with a stud, use a screwdriver to secure a provided screw into the wall at this mark when instructed to do so below.
- 3) For marks that do not align with a wall stud, use a screwdriver to install a provided anchor into the wall at the mark. Engage the head of the anchor with the screwdriver and position the anchor's tip at the mark. Rotate the anchor clockwise while pushing it firmly into the wall. The anchor will automatically drive itself into the wall. Continue rotating until the wide end of the anchor becomes even with the wall surface. Do not over-tighten.
- 4) Return the row of hooks to the wall so that the three holes align with either a stud or an installed anchor. Use a screw driver to secure a screw through each hole and into the installed anchor or stud. Rotate the screws clockwise until tight.

Care Instructions:

Wipe with a soft, dry cloth. Do not use any abrasive or chemical household cleaners.

The hardware included with this item is meant for drywall mounting only. If your wall is made from another material such as concrete or plaster, please consult your local hardware store for assistance in selecting the correct hardware.

Thank you for your purchase
stores | catalog | www.potterybarn.com