

# P O T T E R Y B A R N

## FOUND MIRROR SET OF 3

### Mounting Instructions

The hardware included with this artwork is meant for drywall mounting only. If your wall is made from another material such as concrete or plaster, please consult your local hardware store for assistance in selecting the correct hardware. Since this item is relative large, we recommend that two people work together to mount this item to the wall. This item includes zigzag hardware on the back.

This Mirror only hung vertically

**Tools Required:** Screwdriver, Level, Tape Measure, Pencil, Stud Finder

**Hardware Included:** (1) Screws, (1) Snap-Screw

NOTE: DO NOT USE A CABLE TO HANG THIS ITEM. THE ZIGZAG HARDWARE MUST HANG DIRECTLY FROM THE PROVIDED SCREW
--

### Mounting Instructions:

- 1) With the help of another person, hold the item against a wall at a desired mounting location and with the rear surface facing away from the wall. Use a level to make sure that the item is level and then use a pencil to mark the wall on each side of the item immediately adjacent to the selected pair of Zigzag
- 2) Use a tape measure to measure the distance between the selected pair of ZIGZAG HARDWAREs (measure from the center of each one) on the back of the mirror - this is the "ZIGZAG HARDWARE Distance".
- 3) Use a straightedge and pencil to connect the two marks of Step (1) and then use a tape measure and a pencil to make two "anchor" marks centered on this line. The anchor marks should be spaced apart a distance equal to the "ZIGZAG HARDWARE Distance." These anchor marks are the locations for the hanging hardware.
- 4) If either anchor mark aligns with a wall stud (use a stud finder to determine this), do not use the provided anchors since they cannot penetrate wood. Instead, use a screwdriver to secure only a screw at this location. Rotate the screw clockwise until the screw head is about 3/8 inch from the wall.
- 5) For anchor marks that do not align with a wall stud, use a screwdriver to install an anchor into the wall. Engage an anchor with a screwdriver and then position the anchor tip at one of the marks on the wall. Firmly push the anchor into the wall as you rotate it clockwise. Continue rotating the anchor until the wide end of the anchor aligns with the wall.
- 6) Use the screwdriver to secure a screw into each installed anchor. Rotate the screw clockwise until the screw head is about 3/8 inch from the wall.
- 7) With the help of another person, carefully lift the artwork against the wall so that the ZIGZAG HARDWAREs align with the screw heads – lower the item to engage.

### Care Instructions:

To clean: wipe with a soft, dry cloth. Do not use abrasive or strong chemical household cleaners. A household glass cleaner may be used for the mirror surfaces – spray the cleaner on a clean cloth first

*Thank you for your purchase!*