

POTTERY BARN

Quinn beaded Toilet roll holder Assembly Instructions

Note:

For safe mounting, it is essential to use the proper hardware for your wall type. Contact your local hardware store for assistance, if necessary. For safety and ease of mounting, installation is recommended using two people. Mount to wood studs whenever possible.

Tools Needed:

Level, tape measure, stud finder, Phillips screwdriver, pencil

Parts Included:

- 2 ITW anchors (for dry wall only)
- 2 Metal screws
- 1 Allen wrench
- 1 back plate
- 1 Toilet roll holder

Mounting Instruction

1. Hold the toilet roll holder at desired location. With a pencil, mark on the wall the screw hole location. These marks will be used to determine the location of your mounting hardware.

3. Use a level or measure up from the floor at each mark to ensure the toilet roll holder will be level.

Dry Wall Mounting:

1. Use a Phillips screwdriver to insert the anchors. Do not "push" or drive the anchors into the wall, they are designed to bore into the wall like a drill bit. Slowly turn the anchors clockwise while applying pressure until the flange just touches the wall.
2. Remove back plate from toilet roll holder and place over dry wall anchors and tighten with the help of screws provided.

Stud Mounting:

1. Place the back plate in the marked location on the wall (over a stud).
2. With a Phillips head screw driver insert metal screws into the stud clockwise until tight.

Place toilet roll holder on the mounting plate, tighten Allen screw with wrench provided to secure properly.

Care Instructions:

Wipe with a soft, dry cloth. To protect the finish, do not use household cleaners or abrasives.

Thank you for your purchase

Stores | catalog | www.potterybarn.com