POTTERYBARN

Adair Floor Lamp

Important Safety Instructions:

- For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.
- These instructions are provided for your safety. It is important that they are read carefully and completely before assembling fixture.
- This fixture has been rated for up to (1) **100-watt TYPE A standard bulb** (not included). To avoid the risk of fire, do not exceed the recommended wattage.

Warning:

- To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- · Keep flammable materials away from lit bulb.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Parts Enclosed:

- (A) Lower lamp body
- ❖ (B) Adjustable screw
- (C) Upper lamp body
- ❖ (D) Socket
 - (E) Shade
 - (F) Shade ring

To Assemble:

- 1. Unscrew the shade ring (F) from the socket (D)
- 2. Place shade (E) onto the socket, then secure it by turning the shade ring (F) in a clockwise direction.
- 3. Insert a bulb Max Type A 150 W (not included).
- 4. Slide upper lamp body (B) to a desired location. Turn adjustable screw (C) until tight.
- 5. Plug fixture into outlet.
- 6. Assembly is complete.

Care Instructions:

- Clean with soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage.

