ABOUT MAHOGANY

Our Chatham collection is crafted from responsibly harvested, plantation grown mahogany, a dense hardwood that's ideal for outdoor furniture because it's rich in moisture–resistant oils. The wood is stained and protected with a clear top coat.

WHAT TO EXPECT

As typical of outdoor wood, mahogany will age to a silver gray as the finish weathers and the wood is exposed to the elements.

CARE AND MAINTENANCE

While weathering and color variation over time is natural for wood outdoor furniture, we recommend the following care for best results:

- Store wood furniture indoors out of season. Make sure furniture is completely dry before storage.
- Cover furniture with outdoor covers (sold separately) when left outside during inclement weather or when not in use
- Store cushions separately from furniture to prevent possible transfer of moisture.
- Wipe spills with a clean dry cloth.
- Avoid the use of harsh cleaners and abrasives.

LONG TERM CARE

To revive weathered furniture, sand and clean wood to remove all debris and previous treatment. To refresh color we recommend Sherwin-Williams "Woodscapes" stains. Any one of their select colors may be chosen. Note two coats are required to achieve desired color.

For best results follow their surface preparation and application instructions provided on product. Their selection of colors and additional product details can be found at:

 $\underline{http://www.sherwin-williams.com/homeowners/products/catalog/shelf/exterior-paint-coatings/wood-stains-sealers-clear-topcoats/$